
Content


Chapter 1 System Installation of Faceplate Style.....	1
1.1 Installation Dimension.....	1
1.2 Installation Method.....	10
1.3 Power Supply Connection.....	15
1.5 Paper Roll Instation.....	18
Chapter 2 System Installation of Platform Style.....	26
2.1 Outline Dimension and Function.....	26
2.3 Paper Roll Instation.....	35
2.4 Power Connection.....	36
Chapter 3 Buttons and Indicators.....	38

Chapter 1 System Installation of Faceplate Style

1.1 Installation Dimension

2.1.2●T1 style printer's outline dimension is as the Fig.2-3-1 and Fig.2-3-2 shows. (unit: mm)

- ◆ Outline dimension: 180mm × 110mm × 90mm ;
- ◆ the maximal diameter of the paper roll that the printer admitting is 50mm.



Picture of T1 style

Fig.2-3-1

•T1 style printer's dimension to rivet on the wall and the table-board is as Fig.2-3-2 shows.




Fig.2-3-2

•T1 style printer's outline and configuration is as Fig.2-4 shows.




Fig.2-4

2.2.2 Installing Robbin Cassette (T1 style)

As Fig.2-12 shows, open up the movable cover panel, push it ahead according to the arrow direction as Fig.2-13 shows, then take it down gently (**notice: In the course of pushing, taking down or putting on the movable cover, please protect the tooth which is used to rip the paper from damnification**); The operation to the robbin cassette is same to T0 style, put on the movable cover panel after checking installing well, then close the movable cover panel.




Fig.2-12 Opening up the Movable Pover panel




Fig.2-13 Pushing the Movable Cover Panel

2.3 Installing Paper Roller

2.3.1 Installing Paper Roller (T0 Style)

Installing paper roller needs open up and close the movable cover panel of the print shell too, the course is same to step1 and step4 mentioned in last section. There are two ways to provide paper about WH printers, one is putting the paper roller inside the print shell as the appearance at ex-factory; another is providing paper outside the print shell. Installing paper according to the following steps:

1. Take down the movable cover panel, is same to last section.
2. Cut the paper end like Fig.2-14 shows. For paper roll placed inside the case: As Fig.2-15 shows, place the paper roll outside the print shell first, then insert the paper end downwards into paper-in slot on rear of printer mechanism. It is unreasonable Fig.2-16 shows that insert the paper end upwards into. For paper roll placed outside the case: As Fig.2-17 shows, firstly put paper through the narrow orifice that is at the back of printer shell, then make paper face the paper-in slot.
3. Turn on +5V power supply.
4. Press the button SEL and the SEL indicator will be turned off. Press the button LF to run the print head, and then insert the paper into the paper-in slot, and the paper will be loaded into the print head and come out from the front for a certain seemingly length.

5. Press LF or SEL button again or turn the power off.

6. Put paper end through the paper-out slot that on the movable cover panel, and close the movable cover panel. The way is same to step 4 in last section.

Notice : Notice the direction of the paper when using Thermal series. (See Fig.2-15)

2.3.2 Installing paper roll about T1 style

As Fig.2-12 shows, only to open the movable cover panel, other operation is same to T0 style, there is no repeat here.

2.4 Power Connection

WH micro printer is recommended to use the power connector that matches well to the printer, so that you can directly connect the plug of connector to the socket of printer. **Notice: If use other power supply, it is different for the electric current and voltage of different style, so please consult the User's Manual which is suitable to the style.**

Caution : The polarity of the power shouldn't be connected incorrectly

For WH printers, the column end is positive pole (+), and the board end is negative pole (-), as shown in Fig.2-17




Fig.2-18

System

Caution: Don't connect AC220V with the power socket of the printer directly!

The whole system connection is as Fig.2-18 shows:




Fig.2-17 Power Polarity Sketch Map

三、 Buttons and Indicators

There is an on-line indicator and two buttons (SEL and LF) on the control panel of WH printers. (Add a power indicator and a lack paper indicator to T0 style, add a lack paper indicator to A3 style) The indicators denote the current status of the printer.

3.1 On/off line mode:

(1) The on-line indicator (green light) lights denotes that the printer is online and waiting to receive datas. If the BUSY signal line is on the low level signal, user's host computer could send datas to printer via the interface connection.

(2) The on-line indicator (green light) goes dark indicates the printer is offline or the printer is desposing the datas. At this time, the BUSY signal line is on the high level, user's host computer couldn't send datas to the printer.

(3) Thermal indicator (green light) glinting fleetly indicates there is no paper in the printer. At this time ,the BUSY signal line is on high level, user's host computer couldn't send datas to the printer.

After powered on or exited self-test mode, printer goes in online mode, on-line indicator (green light) lights, holding down SEL button could make the printer switch from one status to another status.

Another function of SEL button is realizing pause during the course of printing. If hold down SEL when printing is going on, then release it, the printer will pause after finished printing the current line, at this time paper feeding mode can be selected. Hold down SEL button again and release it, the printer will continue printing.

A3 Style has a lack paper indicator (red light), the indicator lights indicate that there is paper in the printer, and if the

indicator goes dark, there is no paper in the printer.

T1 Style have a lack paper indicator(yellow light), the indicator lights indicate that there is paper in the printer, and if the indicator goes dark, there is no paper in the printer.

Note: Because some new styles would be produced continuously, so there are some differences about the function or use of the button and the indicator in order to reach some special demands. please consult the **User's Manual which is suitable to the style.**

3.2 Self-test mode:

When the printer goes into self-test mode, the on-line indicator goes dark, and the BUSY signal line is on high level, the host computer could not send data to the printer. The content of self-test receipt includes the characters and Chinese characters. After self-test, the printer is in on-line status and can receive the data from the host computer. Normal self-test indicates the printer (barring interface connection) works normally , otherwise it needs to repair.

▲There are two ways to make the printer go into self-test mode:

(1) Hold down SEL button first, then switch on the power, the printer will begin to self-test print after releasing the SEL button.

(2) When printer works normally, press SEL button to make the indicator go dark, then hold down the LF button, and then hold down the SEL button, the printer would begin to print self-test receipt after the two buttons were released.

(3) When thermal series printer works normally, hold down the LF button and don't release it, then hold down SEL button, the printer begins to print self-test receipt after releasing the two buttons.

▲There are two ways to exit self-test mode:

(1) The printer will exit self-test mode of itself after the self-test receipt printed out.

(2) Shut off the power supply.

● **Paper feeding mode:** When SEL indicator is dark, hold down LF button, then release it, the printer will feed paper empty, but won't print. Hold down LF button and release it again, the print will pause. Hold down SEL button at this

moment, the printer will restore to on-line status. There is single printer that the function of SEL button and LF button is same, the printer will feed paper after pressing random button and the printer will pause feed paper after pressing random button again; some styles have the self-loading formfeed function , or there are some changes about to the two buttons, please consult the **User's Manual which is suitable to the style.**